# **★** COC 1: Install and Configure Computer Systems

- Step 1: Identify Computer Components
- CPU, RAM, HDD/SSD, PSU, Motherboard, GPU
- Input/Output devices (Keyboard, Mouse, Monitor, Printer)
- Practice Task: Open a desktop/laptop case and identify the components.

### Step 2: Assemble a Computer

- 1. Prepare the Workstation (Anti-static mat, tools, power supply off)
- 2. Install the Power Supply Unit (PSU)
- 3. Install the Processor (CPU)
- 4. Apply Thermal Paste and attach the CPU Cooler
- 5. Install RAM Sticks into the motherboard slots
- 6. Mount the Motherboard into the case
- 7. Install Storage Devices (HDD/SSD) and connect cables
- 8. Install the Graphics Card (GPU) if applicable
- 9. Connect all Power Cables (Motherboard, CPU, GPU, Storage)
- 10. Attach the Front Panel Connectors (Power switch, USB, Audio)
- @ Practice Task: Assemble a desktop PC and ensure all components are properly connected.

### Step 3: Install an Operating System (Windows/Linux)

#### **■** Windows 10/11 Installation

- 1. Create a Bootable USB Drive
  - Download the Windows ISO from <u>Microsoft</u>
  - Use Rufus to create a bootable USB
- 2. Set BIOS to Boot from USB
  - Restart PC and enter BIOS (F2, F12, DEL, ESC)
  - Set USB as the first boot device
- 3. Install Windows
  - o Select Language, Time, and Keyboard Layout

- Click Install Now
- Choose Custom: Install Windows only (Advanced)
- Select the drive and format it if needed
- Wait for installation to complete and restart
- 4. Install Drivers and Software
  - Download drivers from the manufacturer's website
  - o Install essential apps (Chrome, Office, Antivirus)
- @ Practice Task: Install Windows 10/11 on a PC or Virtual Machine.


# COC 2: Set Up Computer Networks

- Step 1: Identify Network Components
- Router, Switch, Modem, Access Point
- Cables (Ethernet, Fiber Optic), Connectors (RJ45)
- Practice Task: Identify network devices at home or in a lab.
- Step 2: Set Up a Local Area Network (LAN)
  - 1. Connect the Router to the Modem using an Ethernet cable
  - 2. Connect the Router to a Switch if using multiple devices
  - 3. Connect PCs/Laptops to the Switch using RJ45 cables
  - 4. Assign Static IP Addresses (Optional)
    - Go to Control Panel → Network & Internet → Ethernet Properties
    - Select Internet Protocol Version 4 (TCP/IPv4)
    - Set IP: 192.168.1.X, Subnet: 255.255.255.0, Gateway: 192.168.1.1
- Practice Task: Set up a simple LAN with two computers and test connectivity.

### Step 3: Crimp and Test RJ45 Cables

#### **RJ45 Ethernet Cable Color Codes**

Pin No. T568A (Old Standard) T568B (New Standard - Most Common)



- Straight-through cable: Both ends use T568B (most common)
- Crossover cable: One end uses T568A, the other T568B

### **Steps to Crimp RJ45 Cables**

- 1. **Strip the Cable Jacket** (Use a cable stripper or cutter)
- 2. Align Wires in T568B Order (Recommended)
- 3. Trim Wires to Equal Length (About 1.5 cm)
- 4. Insert Wires into RJ45 Connector
- 5. Use a Crimping Tool to Secure the Connector
- 6. Test the Cable with a LAN Tester

# **★** COC 3: Set Up and Configure Computer Servers

- Step 1: Install Windows Server
  - 1. Download Windows Server ISO from Microsoft
  - 2. Create a Bootable USB and Boot from it
  - 3. Select Language, Time, and Install Now
  - 4. Choose "Windows Server with GUI"
  - 5. Set Admin Password and Login
- @ Practice Task: Install Windows Server in VirtualBox.
- **Guide:** Windows Server Setup

## COC 4: Maintain and Repair Computer Systems and Networks

- Step 1: Diagnose Common Hardware Issues
- No Display (Check RAM, GPU, PSU)
- ✓ Overheating (Check Thermal Paste, Fan)
- ✓ No Boot (Check BIOS, Boot Order)
- @ Practice Task: Troubleshoot a slow computer and suggest fixes.
- Guide: PC Troubleshooting
- Step 2: Perform Preventive Maintenance
- Clean Dust from Components
- Apply New Thermal Paste
- Check for Loose Connections
- **OPERATE SET OF SET OF**
- Guide: PC Maintenance Tips